

**Euro Dance**

**VOICE**

	Voice Name	Voice Type	Voice Number		
			MSB#	LSB#	Prg#(1)
1	Basic Dance Hook	Regular	49	6	1
2	Three Saw Mono	Regular	49	6	2
3	Phat Lines	Regular	49	6	3
4	Raw Square Stack	Regular	49	6	4
5	Dance Fat Poly	Regular	49	6	5
6	Punchy Saw	Regular	49	6	6
7	Magic Chords	Regular	49	6	7
8	Trancy Polyhook	Regular	49	6	8
9	Square Fifth	Regular	49	6	9
10	Simple Tech	Regular	49	6	10
11	Fat Saw Hook	Regular	49	6	11
12	Monster Hook	Regular	49	6	12
13	Basic Polysynth	Regular	49	6	13
14	Sweeping Swell	Regular	49	6	14
15	Pitch Warp Sweep	Regular	49	6	15
16	Falling Sweep	Regular	49	6	16
17	Fat Trance Pad	Regular	49	6	17
18	Uni Six Pad	Regular	49	6	18
19	Fat Saw Pad	Regular	49	6	19
20	Monster Pad	Regular	49	6	20
21	DX100 Bass	Regular	49	6	21
22	Dance Bass Velo	Regular	49	6	22
23	Dance Bass Dark	Regular	49	6	23
24	Deep Rezz Bass	Regular	49	6	24
25	Raw Square Bass	Regular	49	6	25
26	Cool Square Bass	Regular	49	6	26
27	Sub Velo Click	Regular	49	6	27
28	Sub Saw Bass	Regular	49	6	28
29	Digi Mono Bass	Regular	49	6	29
30	Reverse Bass	Regular	49	6	30
31	Brite Punch SQ	Regular	49	6	31
32	JP Short Seq	Regular	49	6	32
33	Ultra Short SQ	Regular	49	6	33
34	Dyno Decay SQ	Regular	49	6	34
35	Fix Start SQ	Regular	49	6	35
36	Growl Saw	Regular	49	6	36
37	Growl Square	Regular	49	6	37
38	Wobbling	Regular	49	6	38
39	White Noise Fall	Regular	49	6	39
40	Dance Power Kit	SFX	126	1	19
41	Power Stabs	Regular	49	6	40
42	Phat Dance Stabs	Regular	49	6	41
43	Smooth Dance Pad	Regular	49	6	42
44	Brite Dance Comp	Regular	49	6	43
45	Dance Power Comp	Regular	49	6	44
46	Slow Reso Sweep	Regular	49	6	45
47	HiPass Sweep	Regular	49	6	46
48	Deep BEF Sweep	Regular	49	6	47
49	Modern Fifth	Regular	49	6	48
50	Square Vibrato	Regular	49	6	49
51	Phat Stack SQ	Regular	49	6	50
52	Simple Saw SQ	Regular	49	6	51
53	RawSquarePerc	Regular	49	6	52
54	Reverse Bass JP	Regular	49	6	53
55	GrowlSquareBass	Regular	49	6	54
56	Brite Rezz Baz	Regular	49	6	55
57	Massive BAXX	Regular	49	6	56
58	Dub Step Bass 1	Regular	49	6	57
59	Dub Step Bass 2	Regular	49	6	58
60	DubStep Attack 1	Regular	49	6	59
61	DubStep Attack 2	Regular	49	6	60
62	Velo Wave Bazz	Regular	49	6	61
63	Magic Yai	Regular	49	6	62
64	Destruct Baz	Regular	49	6	63
65	Dub Step BVelo D	Regular	49	6	64
66	Dub Step BVelo B	Regular	49	6	65
67	Dub Step Menu	Regular	49	6	66
68	Mystic Atmo	Regular	49	6	67
69	Destruct SoundFX	Regular	49	6	68
70	Dub Step Kit	SFX	126	1	20

**STYLE**

Style Name	Style Type
01 Dub Step I	Normal
02 Dub Step II	Normal
03 Electro House	Normal
04 Electro B&B	Normal
05 Why Not House	Normal
06 Chill Step	Normal
07 Dark Spin	Normal
08 Italo Dance	Normal
09 Tajo Beat	Normal
10 Hit Trance	Normal
11 Jagg'R Move	Normal
12 Sax'O'Bit	Normal
13 Black P'Beat	Normal
14 Disco Reggae	Normal
15 Walking Boots	Normal
16 Spacy HipHop	Normal
17 German HipHop	Normal
18 Beon Dance	Normal
19 Summer Groove	Normal
20 Regueton	Normal
21 Reggaetone	Normal
22 Dyskoteka	Normal
23 Latino Dance	Normal
24 Rumba Dance	Normal
25 Dance Field	Normal
26 Poker Beat	Normal
27 Disco Ska	Normal
28 Dollar Beat	Normal
29 sAfrI Dance	Normal
30 Neutrino	Normal
31 Atzen Party	Normal
32 Tik Tak Disco	Normal
33 Arr Pop	Normal
34 Apres Ski	Normal
35 Euro Mix	Normal
36 Turkish Mix	Normal
37 Turkish Party	Normal
38 TurkishTechno	Normal
39 Euro Dance	Normal
40 Balkan Dance	Normal

**REGIST**

Regist Name
1 EURO DANCE 01
2 EURO DANCE 02
3 EURO DANCE 03
4 EURO DANCE 04
5 EURO DANCE 05
6 EURO DANCE 06
7 EURO DANCE 07
8 EURO DANCE 08
9 EURO DANCE 09
10 EURO DANCE 10
11 Style+MPad 01
12 Style+MPad 02

**MULTI PAD**

Name
ArpDown
ArpUp&Down
ArpUpA
ArpUpB
ChordSeq
CombiArpA
CombiArpB
CombiArpC
GatePad
MelodicArp
PumpingPad
StepSeq

**DEMO**

Demo Name
Euro Dance Demo