

PSR-SX920 & SX720

Chinese

VOICE

	Voice Name	Voice Type	Voice Number		
			MSB#	LSB#	Prg#(1)
1	Er Hu 1	Regular	51	1	1
2	Er Hu 2	Regular	51	1	2
3	Ma Tou Qin	Regular	51	1	3
4	Ban Hu	Regular	51	1	4
5	Jing Hu 1	Regular	51	1	5
6	Jing Hu 2	Regular	51	1	6
7	Jing Hu Tremolo	Regular	51	1	7
8	Gao Hu	Regular	51	1	8
9	Pi Pa 1	Regular	51	1	9
10	Pi Pa 2	Regular	51	1	10
11	Pi Pa Tremolo	Regular	51	1	11
12	Liu Qin	Regular	51	1	12
13	Ruan	Regular	51	1	13
14	San Xian	Regular	51	1	14
15	Yang Qin	Regular	51	1	15
16	Gu Zheng 1	Regular	51	1	16
17	Gu Zheng 2	Regular	51	1	17
18	Di Zi 1	Regular	51	1	18
19	Di Zi 2	Regular	51	1	19
20	Xiao 1	Regular	51	1	20
21	Xiao 2	Regular	51	1	21
22	Xun	Regular	51	1	22
23	Sheng 1	Regular	51	1	23
24	Sheng 2	Regular	51	1	24
25	Suo Na 1	Regular	51	1	25
26	Suo Na 2	Regular	51	1	26
27	Hu Lu Si	Regular	51	1	27
28	Ba Wu	Regular	51	1	28
29	Ba Wu & Hu Lu Si	Regular	51	1	29
30	Er Hu Ensemble	Regular	51	1	30
31	China Kit 1	SFX	126	1	33
32	China Kit 2	SFX	126	1	34

STYLE

Style Name	Style Type
01 China Dance	Normal
02 ChinaPopBallad1	Normal
03 ChinaPopBallad2	Normal
04 ChinaPopBallad3	Normal
05 China68SlowRock	Normal
06 China Rock	Normal
07 Kung Fu	Normal
08 West China Pop	Normal
09 2 Person Opera	Normal
10 Beijing Funk	Normal
11 Xi Qing Luo Gu	Normal
12 Zhong Guo Gu Qu	Normal
13 Dong Bei Yang Ge	Normal
14 Yao Zu Min Ge	Normal
15 Chao Xian Min Ge	Normal
16 Zang Zu Min Ge	Normal
17 Yi Zu Min Ge	Normal
18 Xin Jiang Min Ge	Normal
19 GuangDongWuShi	Normal
20 Jing Ju Jie Zou	Normal

DEMO

Demo Name
Ba Wang
Shui Xiang Meng
Zhong Guo Fusion