

Brand	Device Name	Model Number	OS	Confirmed
Google	Pixel 4a	-	12.0	yes
Google	Pixel 5	-	13.0	yes
Google	Pixel 5a	-	14.0	yes
Google	Pixel 6	-	13.0	yes**
Google	Pixel 6a	-	13.0	yes**
Google	Pixel 7	-	13.0	yes**
Google	Pixel 7a	-	13.0	yes**
Google	Pixel 8	-	14.0	yes
Google	Pixel 9	-	15.0	yes
Google	Pixel 9 Pro	-	14.0	yes
Samsung	Galaxy S21	SM-G9910	12.0	yes
Samsung	Galaxy S21 Ultra	SM-G9980	12.0	yes
Samsung	Galaxy S22	SM-S9010	13.0	yes***
Samsung	Galaxy S23 Ultra	SM-S918N	13.0	yes***
Samsung	Galaxy S24 Ultra	SM-S928Q	14.0	yes
Samsung	Galaxy Tab S6 Lite	SM-P615N	12.0	yes
Samsung	Galaxy Tab S7	SM-T870	12.0	yes
Samsung	Galaxy Tab S7 FE	SM-T735N	14.0	yes
Samsung	Galaxy Tab S8	SM-X700	12.0	yes
Samsung	Galaxy Tab S9	SM-X710	14.0	yes

*Actual device behavior may vary depending on the region or service provider

*Some of the device listed above might not be sold in some countries.

*The specification of the Android devices listed above is subject to change for certain reasons of manufacturers.

Please note that they may not operate properly with Smart Pianist depending on the changes.

For detailed specification and information on the Android devices listed above, please contact the manufacturers of them.

*The contents listed are the results of operational checks performed by Yamaha, and do not constitute a guarantee of operation.

Yamaha assumes no responsibility for injuries occurring as a result of using this product.

**Need to update Android 13 QPR2.

***Bluetooth MIDI connection is not established. Please wait for Android 13 QPR2 release.