

List of remote control codes
Liste des codes de commande
Lista de códigos de mando a distancia
遥控器代码列表
리모콘코드목록

TV		Baird	0282	Condor	0161, 0277, 0320, 0323, 0342, 0350, 0351	Elite	0320, 0340, 0350
A.R. Systems	0320	Bang & Olufsen	0180, 0339			Elman	0341
Acme	0342	Basic Line	0282, 0320, 0323, 0340, 0343, 0350	Contec	0179, 0277, 0323, 0342, 0343, 0344	Elta	0277, 0323, 0343
Acura	0323, 0343	Bastide	0282, 0342	Contec/Cony	0012, 0058	Emerson	0000, 0007, 0008, 0012, 0013, 0019, 0026, 0031, 0037, 0051, 0058, 0059, 0161, 0179, 0320, 0339
ADC	0337	Baur	0320, 0349	Continental Edison	0345		
Admiral	0054, 0178, 0336, 0337, 0339, 0346, 0347	Bazin	0282	Cosmel	0323, 0343	Emprex	0154
Advent	0158	Beko	0161, 0269, 0294, 0302, 0311, 0320, 0328, 0351	Craig	0058, 0179	Envision	0008, 0026, 0050
Adventura	0057	Belcor	0008	Crosley	0010, 0037, 0171, 0339	Epson	0155, 0206, 0359
Adyson	0277, 0282, 0342	Bell & Howell	0019, 0054	Crown	0058, 0161, 0171, 0179, 0320, 0323, 0343, 0349, 0350, 0351	Erres	0320, 0349, 0350
Agashi	0277, 0282	Benq	0097, 0242, 0361	CS Electronics	0277, 0340, 0342	ESA	0051
Agazi	0337	Beon	0320, 0349, 0350	CTC Clatronic	0341	ESC	0282
Aiko	0277, 0282, 0320, 0323, 0342, 0343	Best	0161	CTX	0205	Etron	0343
Aim	0320	Bestar	0161, 0320, 0350	Curtis Mathes	0007, 0008, 0010, 0019, 0021, 0026, 0049, 0050, 0178	Eurofeel	0282
Aiwa	0078, 0379	Binatone	0282, 0342	CXC	0058, 0179	Euro-Feel	0337
Akai	0050, 0055, 0109, 0159, 0181, 0277, 0282, 0320, 0323, 0340, 0343, 0349, 0350	Blue Sky	0320, 0340	Cybertron	0340	Euroline	0349
Akiba	0320, 0340	Blue Star	0348	Cytron	0152	Euroman	0161, 0277, 0282
Akura	0320, 0323, 0337, 0340	Boots	0282, 0342	Daewoo	0007, 0008, 0026, 0037, 0053, 0167, 0266, 0275, 0277, 0282, 0315, 0320, 0323, 0331, 0335, 0342, 0343, 0350, 0381, 0465	Euromann	0320, 0337, 0342, 0350
Alaron	0277	BPL	0320, 0348	Dainichi	0277, 0340	Expert	0321
Alba	0161, 0277, 0320, 0323, 0340, 0342, 0343, 0344, 0349, 0351, 0372, 0382	Bradford	0058, 0179	Dansai	0277, 0282, 0320, 0337, 0349, 0350	Exquisit	0320
Albatron	0140	Brandt	0322, 0345	Dantax	0161, 0349	Fenner	0323, 0343
Alcyon	0171	Brilliant	0182	Dawa	0320	Ferguson	0322, 0345, 0349
Alleron	0059	Brinkmann	0320	Daytron	0007, 0008, 0026, 0323, 0343	Fidelity	0277, 0320, 0342, 0346
Allorgan	0282	Brionvega	0320, 0339, 0349, 0350	De Graaf	0346	Filjai	0282
Allstar	0320, 0350	Britannia	0277, 0282, 0342	Decca	0282, 0320, 0342, 0349, 0350	Finlandia	0346
America Action	0179	Brockwood	0008	Dell	0145, 0245	Finlux	0171, 0282, 0320, 0339, 0341, 0342, 0349, 0350
AMOi	0276	Broksonic	0109, 0179	Denver	0358, 0362	FIRST LINE	0342, 0343, 0350
Amplivision	0161, 0282, 0321, 0342	Bruns	0339	Desmet	0320, 0349, 0350	Firstline	0277, 0282, 0320, 0323
Amstrad	0320, 0323, 0337, 0340, 0343	BTC	0340	Diamant	0320	Fisher	0019, 0161, 0282, 0339, 0342, 0344, 0351
Amtron	0058	Bush	0269, 0282, 0283, 0304, 0320, 0323, 0328, 0332, 0340, 0343, 0344, 0346, 0348, 0349, 0350, 0372, 0382, 0463, 0470, 0472	Diamond	0277	Flint	0320, 0350
Anam	0179, 0343	Capsonic	0337	DiamondVision	0135, 0143	Formenti	0171, 0277, 0336, 0339, 0342, 0349
Anam National	0052, 0058	Carena	0320	Dimensia	0049	Formenti/Phoenix	0277
Anglo	0323, 0343	Carnivale	0050	Disney	0219	Fortress	0336, 0339
Anitech	0171, 0320, 0323, 0337, 0343	Carrefour	0344	Dixi	0282, 0320, 0323, 0343, 0349, 0350	Fraba	0161, 0320
Ansonic	0161, 0168, 0320, 0323, 0341, 0343	Carver	0010	Dream Vision	0461, 0498	Friac	0161
AOC	0008, 0026, 0050, 0053	Cascade	0320, 0323, 0343	DTS	0323, 0343	Frontech	0282, 0323, 0337, 0343, 0346, 0347
Apex	0039, 0111, 0217	Casio	0367	Dual	0282, 0320, 0342	Fujitsu	0059, 0069, 0074, 0075, 0282
Arcam	0277, 0282	Cathay	0320, 0349, 0350	Dual-Tec	0342, 0343	Fujitsu General	0282
Arcam Delta	0342	CCE	0183, 0282	Dumont	0008, 0030, 0062, 0282, 0339, 0341, 0342	Fujitsu Siemens	0504, 0505, 0507, 0510, 0511
Aristona	0320, 0349, 0350	Celebrity	0055, 0107	Durabrand	0031, 0051, 0179, 0215	Funai	0051, 0058, 0059, 0112, 0113, 0115, 0118, 0119, 0179, 0337
Arthur Martin	0321	Celera	0039	Dux	0349	Futurtech	0058, 0179
ASA	0339, 0347	Centurion	0320, 0349, 0350	Dwin	0178	Galaxi	0320, 0351
Asberg	0171, 0320, 0350	Century	0339	Dynatron	0320, 0349, 0350	Galaxis	0161, 0320
Astra	0343	CGE	0161, 0171	Dynex	0228, 0231	Gateway	0176, 0177, 0241
Asuka	0277, 0282, 0337, 0340, 0342	Changhong	0039	Elbe	0161, 0168, 0282, 0320	GBC	0323, 0343, 0344
Atlantic	0277, 0320, 0342, 0349, 0350	Chimei	0273	Elcit	0339	GE	0008, 0021, 0023, 0026, 0027, 0031, 0034, 0049, 0052, 0056, 0209
Atori	0323, 0343	Cimline	0323, 0343	Electa	0348	Geant Casino	0321
Auchan	0321	Citizen	0007, 0008, 0026, 0050, 0058	ELECTRO TECH	0343	GEC	0282, 0320, 0342, 0347, 0349, 0350
Audiosonic	0161, 0282, 0320, 0340, 0342, 0343, 0349, 0350	Clatronic	0161, 0171, 0282, 0320, 0323, 0337, 0340, 0342, 0343, 0350, 0351	Electroband	0055, 0107	Geloso	0323, 0343, 0346
AudioTon	0161, 0282, 0342	Clarion	0179	Electrograph	0176	General Technic	0323, 0343
Audiovox	0058, 0179, 0194	Clarivox	0349	Electrohome	0008, 0026, 0052, 0055	Genexxa	0320, 0340, 0347, 0350
Ausind	0171	Commercial Solutions	0021	Element	0230	GFM	0128, 0227
Autovox	0171, 0282, 0337, 0339, 0342	Concerto	0008, 0026	Elin	0277, 0320, 0323, 0342, 0349, 0350	Giant	0282
Aventura	0051	Concorde	0323, 0343				
Awa	0277, 0282						
Axion	0156						

Gibraltar	0008, 0030, 0050, 0062	Ingersol	0323, 0343	Loewe	0161, 0168, 0265, 0320, 0330, 0352	Naonis	0346
GoldHand	0277	Initial	0153	Loewe Opta	0339, 0349, 0350	NEC	0008, 0026, 0050, 0052, 0053, 0072, 0103, 0282, 0344
Goldline	0320	Inno Hit	0171, 0282, 0320, 0323, 0340, 0342, 0343, 0349, 0350	Logik	0054	Neckermann	0161, 0282, 0320, 0339, 0342, 0346, 0349, 0350, 0351
GoldStar	0007, 0008, 0012, 0026, 0031, 0050, 0053, 0161, 0277, 0282, 0320, 0323, 0342, 0343, 0346, 0349, 0350	Innovation	0337, 0343	Luma	0320, 0323, 0346, 0349	NEI	0320, 0349, 0350
Goodmans	0246, 0272, 0282, 0320, 0323, 0337, 0343, 0344, 0349, 0350, 0462, 0473, 0477	Insignia	0131, 0228, 0236, 0238	Lumatron	0282, 0320, 0346, 0349, 0350	Net-TV	0176
Gorenje	0161, 0351	Inteq	0030	Lux May	0350	Neufunk	0320, 0323
GPM	0340	Interactive	0161	Luxman	0008, 0026	New Tech	0343, 0350
GPX	0129	Interbuy	0323, 0343	Luxor	0282, 0342, 0346	New World	0340
Gradiente	0240	Interfunk	0161, 0320, 0339, 0347, 0349, 0350	LXI	0010, 0019, 0021, 0026, 0027, 0031, 0049, 0111	NewTech	0282, 0320, 0323
Graetz	0347	International	0277	M Electronic	0342, 0343, 0345, 0347, 0349, 0350	Nicamagic	0277, 0342
Granada	0171, 0282, 0320, 0321, 0342, 0344, 0346, 0349, 0350	Intervision	0161, 0282, 0320, 0337, 0341, 0342	MAG	0096	Nikkai	0277, 0282, 0320, 0323, 0337, 0340, 0342, 0349, 0350
Grandin	0340, 0343, 0348, 0349	Irradio	0171, 0320, 0323, 0340, 0343, 0349, 0350	Magnadyne	0339, 0341, 0349	Nobliko	0171, 0277, 0341, 0342
Gronic	0282	Isukai	0320, 0340	Magnafon	0171, 0277, 0341, 0342	Nokia	0347
Grundig	0160, 0161, 0171, 0310, 0320	ITC	0282, 0342	Magnavox	0008, 0009, 0010, 0013, 0026, 0032, 0033, 0048, 0050, 0128, 0211, 0212, 0224, 0226, 0239	Norcent	0201
Grunpy	0058, 0059, 0179	ITS	0277, 0320, 0340, 0348, 0350	Magnum	0337, 0343	Nordic	0282
Haier	0157, 0233	ITT	0343, 0347	Majestic	0054	Nordmende	0339, 0345, 0347, 0350
Halifax	0277, 0282, 0337, 0342	ITV	0320, 0343, 0349	Mandor	0337	Nordvision	0349
Hallmark	0008, 0026, 0031	Janeil	0057	Manesth	0282, 0320, 0337, 0342, 0349, 0350	Novatronic	0320
Hampton	0277, 0282, 0342	JBL	0010	Marantz	0008, 0010, 0026, 0050, 0204, 0320, 0349, 0350	Oceanic	0321, 0347
Hanseatic	0161, 0168, 0282, 0320, 0323, 0342, 0343, 0344, 0349, 0350	JC Penney	0007, 0008, 0026, 0027, 0049, 0053, 0056	Marelli	0339	Okano	0161, 0320, 0351
Hantarex	0320, 0323, 0343	JCB	0055, 0107	Mark	0277, 0282, 0320, 0323, 0349, 0350	Olevia	0102, 0199, 0200, 0207, 0222
Hantor	0320	Jensen	0008, 0026	Masuda	0282	ONCEAS	0342
Harman/Kardon	0010	JVC	0012, 0014, 0015, 0056, 0064, 0065, 0067, 0169, 0174, 0297, 0314, 0344, 0350, 0375	Matsui	0282, 0320, 0323, 0342, 0343, 0344, 0346, 0349, 0350, 0455	Onwa	0058, 0179
Harvard	0058, 0179	Kaisui	0277, 0282, 0320, 0323, 0340, 0342, 0343, 0348	Matsushita	0017	Opera	0320
Harwood	0320, 0323	Kamosonic	0342	Maxent	0147, 0176	Oppo	0130
Havermy	0178	Kamp	0277, 0342	Mediator	0320, 0349, 0350	Optimus	0017, 0019
HCM	0282, 0320, 0323, 0337, 0342, 0343, 0348	Kapsch	0347	Medion	0320, 0337, 0343	Optoma	0144
Hema	0282, 0323	Karcher	0161, 0320, 0342, 0343, 0349	Megapower	0140	Optonica	0178
Hewlett Packard	0192	Kawasho	0008, 0026, 0055, 0277	Megatron	0026, 0031	Orbit	0320, 0350
Higashi	0277	KEC	0179	MElectronic	0277, 0282, 0320, 0323	Orion	0043, 0146, 0283, 0320, 0323, 0328, 0343, 0349, 0350
HiLine	0320	Kendo	0161, 0320, 0341, 0346	Melvox	0321	Orline	0320
Hinari	0320, 0323, 0340, 0343, 0344, 0349, 0350	Kenwood	0008, 0026, 0050	Memorex	0019, 0026, 0031, 0053, 0054, 0137, 0215, 0323, 0343	Osaki	0282, 0320, 0337, 0340, 0342
Hisawa	0321, 0340, 0348	KIC	0282	Memphis	0323, 0343	Oso	0340
Hisense	0247	Kingsley	0277, 0342	Mercury	0320, 0323	Otto Versand	0282, 0320, 0336, 0342, 0344, 0348, 0349, 0350
Hitachi	0008, 0012, 0026, 0066, 0084, 0092, 0093, 0120, 0172, 0173, 0255, 0270, 0271, 0282, 0320, 0335, 0338, 0342, 0344, 0346, 0347, 0365, 0382, 0448, 0456, 0467	KLH	0039	Metz	0339	Pael	0277, 0342
Hornophon	0320, 0350	Kloss Novabeam	0057, 0058	MGA	0008, 0026, 0031, 0050, 0053	Palladium	0161, 0282, 0320, 0342, 0351
Hoshai	0340	Kneissel	0161, 0168, 0320	Micromaxx	0337, 0343	Palsonic	0282
Huanyu	0277, 0342	Kolster	0320, 0350	Microstar	0337, 0343	Panama	0277, 0282, 0320, 0323, 0337, 0342, 0343
Hygashi	0277, 0282, 0342	Konka	0340	Midland	0007, 0021, 0023, 0027, 0030, 0056, 0062	Panasonic	0016, 0017, 0020, 0022, 0023, 0035, 0052, 0056, 0084, 0085, 0133, 0163, 0193, 0284, 0286, 0290, 0292, 0320, 0325, 0347, 0356
Hyper	0277, 0282, 0323, 0342, 0343	Korpel	0320, 0349, 0350	Minerva	0171	Panavision	0320
Hypson	0282, 0320, 0321, 0337, 0342, 0348, 0349, 0350	Korting	0161, 0339	Minoka	0320, 0350	Pathe Cinema	0161, 0168, 0277, 0321, 0342
Hyundai	0141	Kosmos	0320	Mintek	0153	Pausa	0323, 0343
Iberia	0320	Koyoda	0343	Mitsubishi	0008, 0026, 0031, 0053, 0066, 0084, 0093, 0098, 0150, 0178, 0289, 0320, 0339, 0344, 0350, 0376	Penney	0021, 0023, 0031, 0050, 0111
ICE	0277, 0282, 0320, 0323, 0337, 0340, 0342, 0343, 0350	KTV	0007, 0050, 0058, 0179, 0183, 0282, 0342	Mivara	0161, 0168, 0171, 0277, 0282, 0342	Perdio	0277, 0320
ICeS	0277	Kyoto	0277, 0282	Monivision	0140	Perfekt	0320
Ilo	0148, 0153	Lasat	0161	Montgomery Ward	0054	Philco	0008, 0009, 0010, 0012, 0026, 0050, 0052, 0053, 0161, 0171, 0320, 0339
IMA	0058	Lenco	0323, 0343	Motion	0171	Philharmonic	0282, 0342
Imperial	0161, 0171, 0320, 0347, 0350, 0351	Lenoir	0323, 0342, 0343	Motorola	0052, 0178	Philips	0008, 0009, 0010, 0011, 0012, 0032, 0048, 0049, 0052, 0122, 0128, 0134, 0186, 0187, 0213, 0221, 0224, 0226, 0239, 0256, 0257, 0259, 0261, 0263, 0267, 0280, 0281, 0287, 0296, 0299, 0301, 0303, 0305, 0313, 0319, 0320, 0324, 0333, 0339,
Indiana	0320, 0349, 0350	Leyco	0320, 0337, 0349, 0350	MTC	0008, 0026, 0050, 0053, 0161, 0277		
Infinity	0010	LG	0031, 0053, 0066, 0116, 0117, 0140, 0161, 0164, 0175, 0195, 0269, 0277, 0282, 0300, 0309, 0317, 0320, 0323, 0328, 0342, 0343, 0346, 0349, 0350, 0366, 0368, 0377, 0466, 0471, 0478	Multi System	0349		
InFocus	0250, 0327, 0363, 0479, 0508	LG/GoldStar	0164	Multitech	0058, 0161, 0179, 0183, 0277, 0282, 0320, 0323, 0341, 0342, 0343, 0344, 0346, 0349		
Ingelen	0347	Liesenk	0349	Murphy	0277, 0342		
		Liesenkotter	0320	NAD	0026, 0031, 0111		
		Life	0337, 0343				
		Lifetec	0320, 0323, 0337, 0343				
		Lloyds	0323				

	0342, 0349, 0350, 0353, 0357, 0360, 0380, 0383, 0452, 0459, 0460	Saisho	0282, 0323, 0337, 0342, 0343	Sony	0038, 0044, 0045, 0047, 0055, 0104, 0105, 0107, 0110, 0123, 0184, 0220, 0248, 0249, 0251, 0252, 0254, 0326, 0343, 0344, 0371, 0374, 0457, 0475	Thomson	0162, 0188, 0189, 0285, 0320, 0322, 0342, 0345, 0350
Philips Magnavox	0011, 0032, 0033	Salora	0346, 0347			Thorn	0320, 0349
Phoenix	0161, 0277, 0320, 0339, 0349, 0350	Sambors	0171, 0341			TMK	0008, 0026, 0031
Phonola	0277, 0320, 0339, 0349, 0350	Sampo	0007, 0008, 0026, 0050, 0176			TNCi	0030
Pilot	0007, 0008, 0050	Samsung	0004, 0005, 0006, 0007, 0008, 0012, 0026, 0031, 0036, 0050, 0053, 0076, 0077, 0079, 0114, 0124, 0125, 0126, 0127, 0139, 0161, 0183, 0185, 0190, 0191, 0258, 0264, 0277, 0282, 0320, 0323, 0334, 0337, 0342, 0343, 0349, 0350, 0351, 0373, 0453, 0468	Sound & Vision	0340, 0341	Tokai	0282, 0320, 0350
Pioneer	0008, 0026, 0094, 0095, 0161, 0320, 0345, 0347, 0349, 0350, 0458	Sandra	0277, 0282, 0342	Soundesign	0008, 0026, 0031, 0058, 0059, 0179	Tokyo	0277, 0342
Plantron	0320, 0323, 0337, 0350	Sansui	0043, 0109, 0320, 0350	Soundwave	0320, 0349, 0350	Tomashi	0348
Playsonic	0282	Sanyo	0008, 0019, 0068, 0070, 0071, 0099, 0161, 0168, 0223, 0237, 0277, 0282, 0288, 0295, 0323, 0342, 0344, 0369, 0469	Squareview	0051	Toshiba	0018, 0019, 0040, 0041, 0046, 0073, 0100, 0103, 0108, 0109, 0111, 0121, 0132, 0166, 0208, 0210, 0214, 0217, 0260, 0268, 0282, 0283, 0293, 0304, 0306, 0307, 0329, 0344, 0355, 0454
Polaroid	0039, 0142, 0202, 0234	SBR	0320, 0349	SSS	0008, 0058, 0179	Totevision	0007
Poppy	0323, 0343	Sceptre	0235, 0244	Standard	0282, 0320, 0323, 0340, 0342, 0343, 0350	Towada	0282, 0347
Portland	0007, 0008, 0026, 0053	Schaub Lorenz	0347	Starlite	0058, 0179, 0320, 0323, 0349	Trakton	0282
Prandoni-Prince	0171, 0346	Schneider	0282, 0316, 0318, 0320, 0333, 0340, 0342, 0349, 0350, 0382	Stenway	0348	Trans Continens	0282, 0320
Precision	0282, 0342	Scotch	0026, 0031	Stern	0346, 0347	Transtec	0277
Prima	0157, 0243, 0323, 0343, 0347	Scott	0008, 0012, 0026, 0031, 0058, 0059, 0149, 0179	Strato	0320, 0323	Trident	0282
Princeton	0140	Sears	0008, 0010, 0019, 0021, 0026, 0027, 0031, 0049, 0051, 0059, 0111	Stylandia	0282	Triumph	0320
Prism	0023, 0056	SEG	0277, 0282, 0320, 0323, 0337, 0341, 0342, 0344, 0349, 0382	Sunkai	0343	Uher	0161, 0171, 0320, 0347, 0350
Profex	0323, 0343	SEI	0339, 0341, 0347	Sunstar	0320, 0323	Ultravox	0277, 0320, 0339, 0341, 0342
Profi-Tronic	0320, 0350	Seleco	0344, 0346, 0347	Sunwood	0320, 0323, 0343, 0350	Unic Line	0320
Proline	0320, 0350	Sencora	0323, 0343	Superla	0277, 0282, 0342	United	0349
Proscan	0021, 0027, 0049	Sentra	0323	Superscan	0013, 0178	Universum	0161, 0171, 0282, 0320, 0337, 0349, 0350, 0351
Prosonic	0161, 0277, 0282, 0320, 0342, 0349, 0282, 0337, 0341, 0342, 0343, 0349, 0350	Serino	0277	SuperTech	0277, 0320, 0323		
Protech	0320, 0342, 0349, 0342, 0343, 0349, 0350	Sharp	0000, 0001, 0002, 0003, 0007, 0008, 0012, 0026, 0060, 0088, 0089, 0091, 0138, 0165, 0170, 0178, 0198, 0229, 0262, 0278, 0279, 0291, 0308, 0312, 0336, 0344, 0354, 0370, 0449, 0450, 0451, 0464, 0474, 0476	Supra	0323, 0343		
Proton	0008, 0012, 0026, 0031	SEI-Sinudyne	0339, 0341, 0347	Supre-Macy	0057		
Protron	0196	Seico	0344, 0346, 0347	Supreme	0055, 0107		
PROVIEW	0096, 0246	Sinudyne	0320, 0339, 0341	Susumu	0340		
Provision	0320, 0349	Sierra	0320, 0350	Sutron	0323, 0343		
Pulsar	0008, 0030, 0062	Siesta	0161	SVA	0151		
Pye	0256, 0320, 0349, 0350, 0378	Signature	0054	Sydnev	0277, 0282, 0342		
Pymi	0323, 0343	Silva	0277	Sylvania	0008, 0009, 0010, 0011, 0013, 0026, 0048, 0050, 0051, 0128, 0227, 0253, 0051, 0058, 0062, 0128, 0179, 0215		
Quandra Vision	0321	Silver	0344	Symphonic	0199		
Quasar	0017, 0023, 0052, 0056	Singer	0321, 0339, 0341	Syntax	0199		
Quelle	0282, 0320, 0337, 0342, 0349, 0350	Sinudyne	0320, 0339, 0341, 0349	Syntax-Brilliant	0199		
Questa	0344	Sheng Chia	0178	Sysline	0349		
Radialva	0320	Shogun	0008	Sytong	0277		
RadioShack	0019, 0021, 0031, 0050, 0179, 0320	Siarem	0320, 0339, 0341	Tandy	0178, 0282, 0336, 0340, 0342, 0347		
RadioShack/Realistic	0007, 0008, 0012, 0026, 0049, 0058	Sierra	0320, 0350	Tashiko	0277, 0282, 0342, 0344, 0346		
Radiola	0282, 0320, 0349, 0350	Siesta	0161	Tatung	0052, 0177, 0282, 0320, 0342, 0349, 0350		
Radiomarelli	0320, 0339	Signature	0054	TCM	0337, 0343		
Radiotone	0161, 0320, 0323, 0350	Silva	0277	Teac	0282, 0320		
Rank	0344	Solavox	0347	Tec	0282, 0323, 0342, 0343		
RCA	0008, 0021, 0024, 0025, 0026, 0027, 0042, 0049, 0052, 0053, 0063, 0136, 0225	Sonitron	0161, 0282	Technics	0017, 0023, 0056		
Realistic	0019, 0031, 0050, 0179	Sonoko	0282, 0320, 0323, 0337, 0342, 0343, 0349, 0350	TechmiSat	0274, 0496, 0497, 0499		
Recor	0320	Sonolor	0321, 0347	Techwood	0008, 0023, 0026, 0056		
Redstar	0320	Sontec	0161, 0320, 0349, 0350	TEDELEX	0282		
Reflex	0320			Teknika	0007, 0008, 0010, 0012, 0026, 0053, 0054, 0058, 0059, 0179		
Revox	0161, 0320, 0349, 0350			Teleavia	0345		
Rex	0337, 0346, 0347			Telecor	0282, 0320		
RFT	0161, 0168, 0339			Telefunken	0320, 0322, 0345, 0350		
Rhapsody	0277			Telegazi	0320		
R-Line	0320, 0349, 0350			Telemeister	0320		
Roadstar	0323, 0337, 0340, 0343			Telesonic	0320		
Robotron	0339			Telestarr	0320		
Rowa	0277, 0282			Teletech	0320, 0323, 0343, 0349		
Royal Lux	0161			Teleton	0282, 0342		
RTF	0339			Televideon	0277		
Runco	0030, 0050, 0062			Televiso	0321		
Saba	0298, 0322, 0339, 0345, 0347			Tensai	0282, 0320, 0323, 0340, 0343, 0350		
				Tesmet	0350		
				Tevion	0337, 0343		
				Texet	0277, 0282, 0323, 0342		
						Yamishi	0282, 0320
						Yokan	0320

Yoko	0161, 0277, 0282, 0320, 0323, 0337, 0340, 0342, 0343, 0349, 0350	Dumont	1026, 1028	JC Penney	1064, 1065, 1068, 1070, 1071	Panasonic	1000, 1022, 1044, 1055, 1068, 1072, 1085, 1090, 1091, 1120, 1121, 1214
Yorx	0340	Durabrand	1114	JCL	1068	Pathe Marconi	1027
Zanussi	0282, 0346	Dynatech	1069	JVC	1007, 1018, 1027, 1039, 1064, 1065, 1066, 1067, 1078, 1089, 1092, 1093, 1094, 1095, 1113, 1208, 1209, 1212, 1213, 1215, 1218	Perdio	1026
Zenith	0008, 0028, 0029, 0030, 0031, 0054, 0061, 0062	Echostar	1018			Philco	1008, 1068
		Elbe	1009			Philips	1006, 1013, 1028, 1035, 1040, 1045, 1046, 1050, 1058, 1059, 1061, 1068, 1076, 1101, 1110, 1113, 1116, 1117, 1122, 1126, 1210, 1211
		Elcatech	1008			Philips Magnavox	1076
		Electrohome	1071			Phonola	1028
		Electrophonic	1071			Pilot	1071
		Elsay	1008			Pioneer	1028, 1036
		Elta	1008, 1009, 1029			Polaroid	1088, 1099
		Emerson	1008, 1020, 1068, 1069, 1071	Kaisui	1008, 1029	Portland	1009, 1025, 1030
		ESC	1009, 1025	Karcher	1028	Prinz	1026
VCR		Etzuko	1008, 1029	Kendo	1008, 1024, 1025, 1030	Profex	1029
ABS	1016	Expressvu	1018	Kenwood	1027, 1064, 1065	Proline	1026
Adventura	1069	Ferguson	1027	Kodak	1068, 1071	Proscan	1019
Adyson	1008	Fidelity	1008, 1026	Korpel	1008, 1029	Prosonic	1009, 1024
Aiwa	1024, 1026, 1027, 1069	Finlandia	1028	Kyoto	1008	Pulsar	1114
Akai	1021, 1027	Finlux	1026, 1027, 1028	Lenco	1025	Pye	1028, 1102
Akiba	1008, 1029	Firstline	1008, 1024, 1029, 1031	Leyco	1008, 1029	Quarter	1065
Akura	1008, 1027, 1029	Fisher	1065	LG	1010, 1026, 1031, 1047, 1054, 1056, 1071, 1103, 1221	Quartz	1065
Alba	1008, 1009, 1024, 1025, 1029, 1030	Flint	1024	Lifetec	1024	Quasar	1068
Alienware	1016	Formenti/Phoenix	1028	Linksys	1016	Quelle	1026, 1028
Ambassador	1030	Frontech	1030	Lloyd's	1069	Radialva	1008
American High	1068	Fuji	1068	Loewe Opta	1028, 1031	RadioShack	1071
Amstrad	1008, 1009, 1026	Fujitsu	1026	Logik	1008, 1029	RadioShack/Realistic	1065, 1068, 1069, 1070, 1071
Anitech	1008, 1029	Funai	1026, 1069	Lumatron	1009, 1025	Radiola	1028
Apex	1088	Galaxy	1026	Luxor	1008	Radix	1071
ASA	1028, 1031	Garrard	1069	LXI	1071	Randex	1071
Asha	1070	Gateway	1016	M Electronic	1026	RCA	1019, 1068, 1070, 1075, 1110, 1113, 1122, 1125
Asuka	1008, 1026, 1028, 1029, 1031	GBC	1029, 1030	Magnavox	1020, 1068, 1114, 1126	Realistic	1065, 1068, 1069, 1070, 1071
Audio Dynamics	1064	GEC	1028	Magnin	1071	ReplayTV	1022, 1123
Audiosonic	1009	Geloso	1029	Manesth	1008, 1029	Rex	1027
Audiovox	1071	General	1030	Marantz	1028, 1064, 1065, 1068	RFT	1008, 1028, 1030
Baird	1009, 1025, 1026, 1027	General Technic	1024	Mark	1009	Ricavision	1016
Bang & Olufsen	1017	GOI	1018	Marta	1071	Roadstar	1008, 1009, 1025, 1029, 1031
Basic Line	1008, 1009, 1024, 1025, 1029, 1030	GoldHand	1008, 1029	Matsui	1024, 1031	Royal	1008
Baur	1028	Goldstar	1026, 1031, 1064, 1071	Matsushita	1068	Runco	1114
Beaumarck	1070	Goodmans	1008, 1009, 1025, 1026, 1029, 1030, 1031	Media Center PC	1016	Saba	1027
Bell & Howell	1065	Gradiente	1069	Mediator	1028	Saisho	1024, 1029
Bestar	1009, 1025, 1030	Graetz	1027	Medion	1024	Samsung	1002, 1034, 1041, 1043, 1057, 1060, 1070, 1084, 1110, 1116, 1122, 1124, 1220, 1222
Black Panther Line	1009, 1025	Granada	1028	MEI	1068	Samurai	1008, 1030
Blaupunkt	1028	Grandin	1008, 1009, 1025, 1026, 1029, 1030, 1031	Memorex	1023, 1026, 1031, 1065, 1068, 1069, 1070, 1071, 1098, 1114	Sanky	1114
Bondstec	1008, 1030	Grundig	1028, 1029	Memphis	1008, 1029	Sansui	1023, 1027, 1106, 1115
Broksonic	1100	Hanseatic	1009, 1028, 1031	MGN Technology	1070	Sanyo	1032, 1065, 1070
Bush	1008, 1009, 1024, 1025, 1029, 1049, 1051, 1063, 1217	Harley Davidson	1069	Micromaxx	1024	Saville	1009
Calix	1071	Harman/Kardon	1064	Microsoft	1016	SBR	1028
Candle	1070, 1071	Harwood	1008	Microrstar	1024	Schaub Lorenz	1026, 1027
Canon	1068	HCM	1008, 1029	Migros	1026	Schneider	1008, 1009, 1024, 1025, 1026, 1028, 1029, 1030, 1031
Cathay	1009	Headquarter	1065	Mind	1016	Sears	1065, 1068, 1071
Catron	1030	Hewlett Packard	1016	Mitsubishi	1026, 1028, 1079	SEG	1008, 1009, 1029
CGE	1026, 1027	Hinari	1008, 1009, 1024, 1029	Motorola	1068	SEI-Sinudyne	1028
Cimline	1008, 1024, 1029	Hisawa	1024	MTC	1070	Selec	1027
CineVision	1104	Hitachi	1011, 1026, 1027, 1028, 1046, 1062	Multitech	1008, 1026, 1028, 1029, 1030, 1069, 1070	Sentra	1008, 1030
Citizen	1070, 1071	HNS	1110	Murphy	1026	Sentron	1008, 1029
Clatronic	1008, 1030	Howard Computers	1016	NEC	1027, 1064, 1065	Sharp	1003, 1033, 1077, 1107, 1127, 1219
Colortyme	1064	HP	1016	Neckermann	1027, 1028	Shintom	1008, 1029
Condor	1009, 1025, 1030	HTS	1018	NEI	1028	Shivaki	1031
Craig	1070, 1071	Hughes	1111, 1113, 1122	Nesco	1008, 1029	Shogun	1070
Crown	1008, 1009, 1025, 1029, 1030	Hughes Network Systems	1110, 1116	Nikkai	1008, 1009, 1030	Siemens	1031
Curtis Mathes	1064, 1068, 1070	Humax	1012, 1110, 1113	Nikko	1071	Silva	1031
Cybernex	1070	Hush	1016	Niveus Media	1016	Silver	1009
CyberPower	1016	Hypson	1008, 1009, 1024, 1029	Noblex	1070	Singer	1068
Daewoo	1009, 1025, 1030, 1038, 1069, 1223	iBUYPOWER	1016	Nokia	1009, 1027	Sinudyne	1028
Dansai	1008, 1009, 1029	Impego	1030	Nordmende	1027	Solavox	1030
Dantax	1024	Imperial	1026	Northgate	1016	Sonic Blue	1022, 1123
Daytron	1009, 1025	Inno Hit	1008, 1009, 1025, 1028, 1029, 1030	Oceanic	1026, 1027		
DBX	1064	Innovation	1024	Okano	1008, 1009, 1024		
De Graaf	1028	Instant Replay	1068	Olympus	1068		
Decca	1026, 1027, 1028	Interbuy	1008, 1031	Optimus	1071		
Decca	1026, 1027, 1028	Interfunk	1028	Orion	1023, 1024, 1051, 1115, 1217		
Dell	1016	Intervision	1009, 1026	Orson	1026		
Denko	1008	Irradio	1008, 1029, 1031	Osaki	1008, 1026, 1029, 1031		
DiamondVision	1096	ITT	1027	Otto Versand	1028		
DigiFusion	1014	ITV	1009, 1025, 1031	Palladium	1008, 1027, 1029, 1031		
DigiFusion	1019, 1105, 1110, 1111, 1113, 1116, 1122						
DIRECTV	1111, 1113, 1116, 1122						
Dish Network	1018						
Dishpro	1018						
Dual	1009, 1027, 1028						

Sonneclair	1008	Airis	2364	Easy Home	2359	Limit	2355
Sonoko	1009, 1025	Aiwa	2322	Eclipse	2354	Liquid Video	2158
Sontec	1031	Akai	2145, 2177, 2179, 2248	E-Dem	2364	Liteon	2043, 2051, 2142
Sony	1001, 1016, 1048, 1053, 1073, 1074, 1080, 1081, 1082, 1083, 1108, 1118, 1216	Akura	2356	Electrohome	2362	Loewe	2320
Stack	1016	Alba	2064, 2165, 2186, 2337, 2346	Elin	2362	LogicLab	2355
Stack 9	1016	Alco	2149	Elta	2341, 2361, 2362	Magnavox	2025, 2050, 2137, 2150, 2159, 2224, 2230, 2358
Standard	1009, 1025	Alize	2361	Emerson	2129, 2137, 2150	Magnex	2367
Stern	1009	Allegro	2133	Enterprise	2129	Majestic	2360
STS	1068	Amitech	2362	Enzer	2380	Marantz	2328
Sunkai	1024	Amphion MediaWorks	2195	Epson	2247	Marquant	2362
Sunstar	1026	AMW	2195, 2363	ESA	2137	Matsui	2148, 2378
Suntronic	1026	Apex	2030, 2124, 2125, 2126, 2127, 2130, 2131	Finlux	2354, 2362, 2367	McIntosh	2199
Sunwood	1008, 1029	Apple	2241	Fintec	2377	Mecotek	2362
Superscan	1020	Arrgo	2138	Funai	2137	Medion	2182
Sylvania	1020, 1068, 1069, 1102, 1126	Asono	2364	Gateway	2051	Memorex	2028, 2145, 2234
Symphonic	1008, 1069, 1126	Aspire	2152, 2222	GE	2029, 2131, 2156	MiCO	2354, 2382
Systemax	1016	Astar	2240	Gericom	2351	Micromaxx	2182
Tagar Systems	1016	ATACOM	2364	GFM	2226	Microsoft	2156
Taisho	1024	Audiovox	2061, 2149	Giec	2382	Microstar	2182
Tandberg	1009	Avioius	2367	Global Solutions	2355	Minoka	2362
Tandy	1065	Awa	2363	Global Sphere	2355	Minowa	2367
Tashiko	1026, 1071	Axion	2249	Go Video	2133, 2213	Mintek	2131, 2245
Tatung	1026, 1027, 1028	Bang & Olufsen	2128	Goodmans	2165, 2280, 2291, 2358, 2371, 2376, 2382	Mitsubishi	2003
TCM	1015, 1024, 1042	Baze	2367	GPX	2227	Mizuda	2358, 2359
Teac	1009, 1069	BBK	2364	Gradiente	2151	Monyka	2380
Tec	1008, 1009, 1030	Bellagio	2363	Graetz	2380	Mustek	2186
Technics	1068	Best Buy	2359	Greenhill	2131	Mx Onda	2354
Teknika	1068, 1069, 1071	Blaupunkt	2131	Grundig	2349	Mystral	2366
Teleavia	1027	Blue Parade	2157	Grunkel	2362, 2366	Naiko	2362
Telefunken	1027	Boghe	2382	GVG	2377	Nesa	2131
Teletech	1008, 1009	Brainwave	2362	H&B	2358	Neufunk	2380
Tenosal	1008, 1029	Brandt	2148, 2188	H_her	2364	Nevir	2362
Tensai	1008, 1026, 1029, 1031	Broksonic	2145, 2146	Haaz	2354, 2355	Next Base	2143
Tevion	1024	Bush	2064, 2110, 2170, 2268, 2290, 2346, 2358, 2367, 2383	Haier	2254	Nexstech	2243
Thomson	1005, 1027	California Audio Labs	2151	Harman/Kardon	2047, 2135	NU-TEC	2383
Thorn	1027	Cambridge Audio	2354	HiMAX	2359	Onkyo	2159, 2368
Tivo	1108, 1110, 1111, 1113, 1117, 1118, 1119, 1122	CAT	2352, 2353	Hitachi	2062, 2090, 2115, 2274, 2282, 2316, 2359, 2380	Oopla	2051
TMK	1070	CAVS	2192	Hitek	2130	Oppo	2196, 2255
Tokai	1008, 1029, 1031	Centrum	2353	Home Tech Industries	2364	Optim	2381
Tonsai	1029	CAVS	2192	Hyundai	2366	Optimus	2180
Toshiba	1004, 1016, 1027, 1028, 1037, 1049, 1052, 1086, 1087, 1097, 1109, 1112, 1194	CGV	2354, 2362	Ilo	2245	Orava	2358
Totevision	1070, 1071	Changhong	2140	Initial	2131, 2245	Orbit	2363
Touch	1016	Cinetec	2363	Innovation	2182	Orion	2073, 2110
Towada	1008, 1029	CineVision	2133, 2237	Integra	2157	Oritron	2148, 2158
Towika	1008, 1029	Clatronic	2358, 2367	Irradio	2053	P&B	2358
TVA	1030	Coby	2031, 2046, 2360	iSymphony	2246	Pacific	2355
Uher	1031	Conia	2383	JBL	2135	Panasonic	2011, 2024, 2034, 2042, 2058, 2062, 2066, 2067, 2093, 2116, 2117, 2118, 2119, 2120, 2121, 2122, 2123, 2151, 2159, 2164, 2166, 2167, 2172, 2173, 2175, 2209, 2214, 2275, 2277, 2278, 2281, 2282, 2283, 2301, 2374, 2470
UltimateTV	1019	Continental Edison	2363	JVC	2020, 2096, 2097, 2099, 2100, 2101, 2102, 2103, 2106, 2107, 2160, 2257, 2260, 2262, 2263, 2321, 2324, 2326, 2327, 2343, 2464, 2465, 2468, 2469, 2471	Parasound	2197
Ultravox	1009	Crown	2362	Jwin	2198	peeKTON	2364
Unitech	1070	C-Tech	2355	Kansai	2360	Philips	2008, 2012, 2025, 2044, 2050, 2051, 2053, 2060, 2072, 2108, 2111, 2147, 2159, 2163, 2169, 2174, 2181, 2185, 2230, 2261, 2266, 2267, 2286, 2287, 2289, 2295, 2300, 2302, 2317, 2328, 2338, 2342, 2350, 2467
United Quick Star	1009, 1025	Curtis Mathes	2139	Kawasaki	2149	Phonotrend	2367
Universum	1026, 1028, 1031	CVG	2377	Kenex	2362	Pioneer	2016, 2017, 2018, 2019, 2035, 2092, 2094, 2095, 2109, 2157, 2180, 2190, 2212, 2269, 2272, 2299, 2304, 2305, 2306, 2307, 2308, 2309, 2310, 2311, 2344, 2345, 2347, 2379
Vector Research	1064	CyberHome	2022, 2098, 2138, 2187, 2336	Kenwood	2041, 2151, 2348	Pointer	2362
Video Concepts	1064	Cytron	2244	KeyPlug	2362	Polaroid	2125, 2215, 2235
Videon	1024	Daenyx	2363	Kiuro	2362	Portland	2362
Videosonic	1070	Daewoo	2001, 2133, 2276, 2298, 2330, 2362, 2363, 2377	Kingavon	2358	Powerpoint	2363
Viewsonic	1016	Daewoo International	2363	Kiss	2380		
Voodoo	1016	Dalton	2357	KLH	2131, 2149		
Wards	1068, 1069, 1070, 1071	Dansai	2362, 2381	Koda	2358		
Weltblick	1031	Daytek	2184, 2195, 2363	Koss	2013, 2148, 2158		
XR-1000	1068, 1069	Dayton	2363	KXD	2359		
Yamaha	1064, 1065	DEC	2358	Landel	2143		
Yamashi	1008, 1029	Decca	2362	Lasonic	2132		
Yokan	1008, 1029	Denon	2059, 2151, 2193, 2332	Lawson	2355		
Yoko	1008, 1029, 1030, 1031	Denver	2356, 2358, 2360, 2370	Lecson	2381		
Zenith	1114	Denzel	2380	Lenco	2358, 2362, 2367		
ZT Group	1016	Desay	2205	Lenoxx	2136, 2153		
		Diamond	2354, 2355	LG	2002, 2033, 2038, 2057, 2129, 2133, 2189, 2191, 2223, 2238, 2270, 2288, 2335, 2373, 2375		
		DiamondVision	2225, 2232				
		Disney	2010, 2028				
		DK Digital	2339				
		Dmtech	2176				
		Dual	2380				
		Durabrand	2136				
		DVX	2355				
				Life	2182		
				Lifetec	2182		

DVD

4Kus	2051
Accurian	2142
Advent	2155, 2251
AEG	2362

Prima	2252	Teac	2149, 2333, 2355,	Hitachi	2062	HomeChoice	3106
Proceed	2130	Tec	2383	Insignia	2002	Humax	3021, 3080, 3083
Proscan	2156	Technics	2356	Irradio	2053	ITT Nokia	3097
Prosonic	2360, 2377	Technika	2151	JVC	2100, 2101, 2106,	Jasco	3123
Protron	2202	Telefunken	2362, 2367	LG	2107	Jerrold	3017, 3018, 3025,
Provision	2358	Tensai	2353		2033, 2057, 2223,		3066, 3072, 3084,
Pye	2144	Tevision	2362		2238		3090, 3096, 3119,
Qwestar	2148	Theta Digital	2182, 2355, 2357	Liteon	2043		3123
Raite	2380	Thomson	2157	Panasonic	2011, 2034, 2058,	JVC	3099
RCA	2021, 2029, 2104,		2183, 2188, 2334,		2062, 2116, 2117,	Kabel Deutschland	
	2105, 2131, 2149,	Tokai	2372		2119, 2120, 2121,		3024, 3027, 3121
	2156, 2157, 2229	Top Sucess	2356, 2380		2123	Macab	3101
RedStar	2356, 2360, 2362	Toshiba	2364	Philips	2008, 2044, 2050,	Magnavox	3079
Regent	2153		2032, 2036, 2037,		2051, 2147	Maspro	3099
Reoc	2355		2039, 2048, 2049,	Pioneer	2017, 2035	Matsui	3099
Rimax	2361		2054, 2055, 2072,	Pye	2144	MegaCable	3117
Rio	2133		2073, 2076, 2078,	Samsung	2000, 2112, 2216	Memorex	3076, 3122
Roadstar	2331, 2358		2079, 2086, 2145,	Sansui	2073	Minerva	3099
Ronin	2363		2159, 2218, 2233,	Sanyo	2217	Mnet	3107
Rotel	2203		2256, 2259, 2296,	Sony	2004, 2005, 2007,	Motorola	3025, 3026, 3084,
Rowa	2154, 2383		2369		2052, 2068, 2069,		3088, 3090, 3095,
Rownsonic	2353	TRANScontinents	2363, 2367		2074, 2208, 2210,		3117
Saba	2148, 2188	Transonic	2367		2211	Movie Time	3077, 3109
Sabaki	2355	Trio	2362	Sylvania	2239	Mr Zapp	3101
Saivod	2362	Trutech	2242	Toshiba	2032, 2036, 2037,	Multichoice	3107
Sampo	2141	TruVision	2359		2039, 2049, 2054,	Multitech	3127
Samsung	2000, 2045, 2077,	TSM	2364		2055, 2076	NEC	3064
	2112, 2113, 2114,	Umax	2361	Yamaha	2056	NET Brazil	3085
	2115, 2151, 2200,	United	2367			Nokia	3097
	2216, 2219, 2228,	Urban Concepts	2159			Noos	3101
	2264, 2265, 2271,	US Logic	2245	Cable		NSC	3077
	2279, 2294, 2303,	Venturer	2149	ABC	3002, 3003, 3017,	Oak	3074
	2329, 2365	Viewmaster	2364		3066, 3067, 3086,	Pace	3006, 3089, 3121
Sansui	2073, 2145, 2354,	Vocopro	2206		3093, 3119, 3122	Palladium	3099
	2355, 2362	VocoStar	2207	ADB	3020	Panasonic	3112, 3118, 3122
Sanyo	2134, 2145, 2217,	Waitec	2364	Adelphia	3081	Paragon	3122
	2292	Welltech	2382	Alcatel	3016	Philips	3068, 3071, 3079,
ScanMagic	2186	Westinghouse	2063, 2250	Americast	3124		3099, 3100, 3101,
Schaub Lorenz	2362	Wharfedale	2354, 2355	Amstrad	3022, 3098		3103
Schneider	2176	Woxter	2361, 2364	Antronix	3065, 3070	Pioneer	3001, 3006, 3094,
Scientific Labs	2355	Xbox	2156, 2183	Archer	3070		3098, 3114, 3116,
Scott	2161, 2357	Xlogic	2355, 2362	Arcon	3098		3120
Seeltech	2364	XMS	2362	AT&T	3095	Popular Mechanics	
SEG	2162, 2355, 2363,	Xoro	2382	Axis	3098		3126
	2380	Yamada	2051, 2361, 2363	Bell South	3124	Proscan	3066, 3093
Sharp	2006, 2040, 2088,	Yamaha	2056, 2064, 2065,	Cable Vision	3092	Pulsar	3122
	2091, 2182, 2194,		2080, 2081, 2082,	Cabletenna	3065	PVP Stereo Visual Matrix	
	2220, 2221, 2231,		2083, 2089, 2118,	Cabletime	3104		3018
	2236, 2293, 2340		2151, 2323	Cableview	3087	Quasar	3122
Shinsonic	2245	Yamakawa	2363, 2380	Clearmaster	3127	RadioShack	3123, 3127
Sigmatek	2359, 2364	Yukai	2186	ClearMax	3127	RCA	3030, 3031, 3087,
Silva	2356	Zenith	2002, 2129, 2133,	Clyde Cablevision	3105		3118
Singer	2354, 2355		2159, 2223	Colour Voice	3068	Realistic	3070
Skymaster	2325, 2355			Comcast	3084, 3088, 3117	Recoton	3126
Skyworth	2356	Blu-ray Disc		Comcrypt	3107	Regal	3078
Slim Art	2362	LG	2033	Comtronics	3069	Regency	3075
SM Electronic	2355	Panasonic	2011, 2209, 2214	Contec	3074	Rembrandt	3066
Sonic Blue	2133	Pioneer	2212	Coolmax	3127	Runco	3122
Sontech	2366	Samsung	2045, 2113	COX	3084	Sagem	3101
Sony	2004, 2005, 2007,	Sharp	2194, 2220, 2221	Cryptovision	3110	Samsung	3069, 3089, 3114,
	2009, 2014, 2015,	Sony	2075	Director	3084		3120
	2023, 2026, 2027,	Yamaha	2064	Eastern	3075	SAT	3098
	2052, 2068, 2069,			Everquest	3123	Scientific Atlanta	3000, 3001, 3002,
	2070, 2071, 2074,			Fidelity	3098		3003, 3006, 3028,
	2075, 2084, 2085,			Filmnet	3107		3029, 3081, 3086,
	2087, 2168, 2171,	DVR		Filmnet Cablecrypt	3111		3089, 3094, 3095,
	2208, 2210, 2211,	Bush	2110		3111		3108
	2258, 2273, 2284,	Hitachi	2090	Filmnet Comcrypt	3111	Signal	3072, 3123
	2285, 2312, 2313,	Panasonic	2066, 2067, 2093,		3111	Signature	3066
	2314, 2315, 2318,		2116, 2117, 2119,	Finlux	3097	Sony	3092, 3125
	2319, 2466		2120, 2122, 2123	Focus	3126	Sprucer	3118
Soundmaster	2355	Philips	2108, 2111	Foxtel	3022	Standard Component	3115
Soundmax	2355	Pioneer	2016, 2017, 2018,	France Telecom	3100, 3101		3115
Spectra	2363		2019, 2092, 2094,	Freebox	3023	Starcom	3017, 3072, 3119,
Spectroniq	2201		2095, 2109	GC Electronics	3070		3123
Standard	2355	RCA	2105	GE	3066, 3093	Stargate	3072, 3123
Star Cluster	2355	Samsung	2113, 2219	GEC	3105	Starquest	3072, 3123
Starmedia	2358, 2364	Sharp	2088, 2091	Gemini	3072, 3123	Supercable	3090
Sungale	2204	Sony	2084, 2085, 2087	General Instrument		Supermax	3127
Sunkai	2362	Toshiba	2086		3017, 3025, 3066,	Tele+1	3107, 3111
Superscan	2150	Yamaha	2089, 2118		3084, 3090, 3096,	Telepiu	3107
Supervision	2355				3117	Thomson	3082, 3091
Sylvania	2012, 2137, 2150,	DVD Recorder		Goldstar	3120	TIME WARNER	3084
	2178, 2230, 2239	Aspire	2222	Gooding	3099	Tocom	3067
Symphonic	2108, 2230	Astar	2240	Grundig	3098, 3099	Torx	3017
Synn	2355	Broksonic	2146	Hamlin	3073, 3078	Toshiba	3122
T.D.E. Systems	2366	Go Video	2213	Hirschmann	3097	Tristar	3127
Tatung	2001, 2362			Hitachi	3066	Tudi	3102
TCM	2182, 2297					Tusa	3072, 3123

TV86	3077	Conrad Electronic	4217, 4219	Grundig	4006, 4004, 4015, 4035, 4211, 4218, 4222	Mega	4055, 4053
Unika	3065, 3070	Contec	4050	Hänsel & Gretel	4219	Memorex	4127
United Cable	3018, 3119	Coolsat	4096	Hantor	4001, 4013	Metronic	4031, 4028, 4001, 4004, 4005, 4010, 4217
Universal	3065, 3070	Cosat	4048	Hanuri	4010	Metz	4015
Universum	3097, 3099	Coship	4109	Hauppauge	4044	Micro electronic	4218, 4219, 4217
V2	3127	Crown	4011	Helioacom	4219	Micro Technology	4217
Videoway	3019	Daeryung	4014	Helium	4219	MicroGem	4106
View Star	3074, 3077, 3079	Daewoo	4057, 4217	Hinari	4007	Micromaxx	4024, 4008
Viewmaster	3127	DDC	4007	Hirschmann	4024, 4015, 4210, 4218, 4219, 4216	Microstar	4008
Vision	3127	Delega	4007	Hisawa	4013	Microtec	4217
Visiopass	3097, 3100, 3101	Dew	4050	Hisense	4016	Minerva	4015
Vortex View	3127	Diamond	4051	Hitachi	4114, 4006, 4199, 4203	Mitsubishi	4006, 4015, 4202
Wittenberg	3098	Digitality	4219	Homecast	4087, 4084, 4085	Mitsumi	4054
Zenith	3113, 3122, 3124	Digital Stream	4105	Houston	4048	Morgan's	4011, 4054, 4055, 4053, 4217
Zentek	3126	DIRECTV	4056, 4064, 4067, 4068, 4070, 4071, 4074, 4107, 4116, 4119, 4121, 4122, 4123, 4127, 4192, 4193, 4194, 4195, 4196, 4197, 4198, 4199, 4200, 4201, 4202, 4203, 4206, 4207, 4221	HTS	4117	Motorola	4090, 4091, 4088, 4019
Sattelite							
AB Sat	4216, 4217	Discoverer	4212	Hughes	4064, 4068, 4194, 4192, 4196, 4202	Multichoice	4222
AccessHD	4104	Discovery	4216	Hughes Network Systems	4071	Multitec	4212
ADB	4220	Diseqc	4216	Humax	4097, 4025, 4030, 4060	Muratto	4049
AGS	4216	Dish Network	4018, 4065, 4089, 4092, 4094, 4095, 4117	Huth	4005, 4011, 4012, 4013, 4050, 4048, 4219, 4223	Mysat	4217
Akai	4053, 4055	Dishpro	4018, 4117	Hypson	4031	Navex	4013
Alba	4001, 4004, 4006, 4007, 4062, 4217	Distrisat	4053	Ilo	4016	Neuhaus	4009, 4048, 4218, 4219, 4217
Aldes	4005, 4007, 4010	Ditristrad	4048	Imex	4031	Neusat	4217
Allsat	4048, 4053, 4055	DNT	4014, 4053, 4055	Innovation	4008	Next Level	4019
Allsonic	4005, 4008, 4024	Drake	4072	Insighnia	4107	NextWave	4223
Alltech	4217	DStv	4222	Intertronic	4011	Nikko	4011, 4217
Alpha	4053	Dune	4024	Intervision	4048, 4219	Nokia	4006, 4040
Alpha Digital	4104	Echostar	4014, 4018, 4065, 4089, 4117, 4217	ITT Nokia	4006	Nordmende	4001, 4006, 4007, 4010, 4052
Alphastar	4077	Einhell	4001, 4005, 4011, 4217, 4218	Jerrold	4019	Nova	4222
Amitronica	4217	Elap	4216, 4217	Johansson	4013	Novis	4013
Amstrad	4011, 4035, 4217, 4218	Elekta	4010	JOK	4216	Oceanic	4051
Anglo	4217	Elsat	4217	JSR	4048	Octagon	4001, 4004, 4050
Ankaro	4005, 4008, 4024, 4217	Elta	4001, 4008, 4024, 4048, 4053, 4055	JVC	4089, 4065, 4117, 4029	Okano	4011
Anttron	4001, 4004	Emanon	4001	Kamm	4217	Optex	4048
Apollo	4001	Emme Esse	4008, 4024	Kathrein	4015, 4055, 4053, 4063, 4034, 4042, 4215, 4216, 4217	Optus	4213, 4222, 4223
Armstrong	4011, 4053	Engel	4217	Kathrein Eurostar	4215	Orbitech	4001, 4212, 4213, 4218
Artec	4100	Ep Sat	4006	Klap	4216	OSat	4004
Asat	4053, 4055	EURIEULT	4031	Konig	4219	Otto Versand	4015
ASLF	4217	Eurodec	4052	Kosmos	4049	Pace	4006, 4015, 4035, 4043, 4047, 4216
Astacom	4216	Europa	4053, 4218, 4219	KR	4004	Pacific	4051
Astra	4009, 4011, 4054, 4217, 4219	Europhon	4219	Kreiselmeyer	4015	Packsat	4216
Astro	4004, 4008, 4010, 4015, 4024, 4213, 4218, 4219	Eurosat	4011	K-SAT	4217	Palcom	4007
AudioTon	4004, 4048	Eurosky	4024, 4011, 4008, 4215, 4218, 4219	Kyostar	4001	Palladium	4011, 4218
Aurora	4222	Eurostar	4011, 4215, 4219	L&S Electronic	4024	Palsat	4212, 4218
Austar	4222	Eutelsat	4217	Lasat	4024, 4010, 4008, 4054, 4215, 4212, 4219	Panasat	4222
Axiel	4216	Exator	4001, 4004	Lasonic	4108	Panasonic	4121, 4126, 4124, 4006, 4035, 4036, 4221, 4198
Axis	4008, 4009, 4024, 4050	Expressvu	4117	Lenco	4024, 4001, 4049, 4215, 4219, 4217	Panda	4006, 4219
Best	4008, 4024	Fenner	4024, 4212, 4217	Leng	4013	Pansat	4125
Blaupunkt	4015	Ferguson	4006, 4052, 4214	Lennox	4048	Patriot	4216
Blue Sky	4217	Fidelity	4218	Lenson	4218	Paysat	4127
Boca	4011, 4054, 4059, 4217	Finlandia	4006	Lexus	4053	PCT	4110
Boston	4216	Finlux	4006	LG	4103, 4107, 4049	Philco	4101
Brain Wave	4013	FinnSat	4050, 4052	Lifesat	4024, 4008, 4212, 4217	Philips	4071, 4068, 4127, 4006, 4055, 4053, 4061, 4033, 4213, 4216, 4196, 4202, 4203, 4201, 4206
Broadcast	4012	Flair Mate	4217	Lifetec	4008	Phoenix	4050
Broco	4217	Foxtel	4222	Lorenzen	4219	Phonotrend	4006, 4005, 4048
BSkyB	4035, 4041	Freecom	4001, 4049, 4218	Lorraine	4049	Pioneer	4046, 4213
BT	4216	FTEmaximal	4024, 4217	Lupus	4024, 4008	Polsat	4052
Bubu Sat	4217	Fuba	4024, 4001, 4008, 4014, 4015, 4055, 4215	Luxor	4218	Predki	4013
Bush	4006, 4045	Galaxis	4024, 4005, 4008, 4009, 4050, 4048, 4215, 4222	Lyonnaise	4052	Premiere	4048, 4213
Cambridge	4218	GE	4093, 4066, 4111, 4197	Macab	4052	Priesner	4011
Canal Satellite	4213	General Instrument	4073, 4019	Magnavox	4127, 4101	Primestar	4076
Canal+	4213	GMI	4011	Manata	4031, 4216, 4217	Profile	4216
CaptiveWorks	4099	GOI	4117	Manhattan	4006, 4010, 4048, 4216	Promax	4006
Channel Master	4007, 4110	Goldbox	4213	Marantz	4055	Prosat	4007, 4005
Chaparral	4075	GoldStar	4049	Mascom	4010	Proscan	4093, 4066, 4122, 4197
CHEROKEE	4216	Goodmans	4029, 4002, 4006	Maspro	4006, 4217	Protek	4051
Chess	4212, 4217	Goodmind	4111	Matsui	4216	Proton	4016
CityCom	4006, 4215, 4219	Grandin	4031	Max	4219	Provision	4010
Clatronic	4013	Grothusen	4001, 4049	Mediabox	4213	Quadral	4024, 4007, 4005, 4008, 4216
CNT	4010			Mediamarkt	4011	Quelle	4015, 4215, 4219
Comag	4080, 4081, 4082, 4083, 4086			Mediasat	4009, 4213, 4218	Quiero	4052
CommLink	4005			Medion	4024, 4008, 4217	RadioShack	4019
Comtech	4050			Medison	4217	Radiola	4055, 4053
Condor	4008, 4024, 4219					Radix	4014, 4037
Connexions	4014, 4024						
Conrad	4024, 4215, 4218, 4219						

Rainbow 4004
RCA 4093, 4066, 4112, 4113, 4118, 4119, 4116, 4122, 4197, 4207
Realistic 4078
Redpoint 4009
Redstar 4024, 4008
RFT 4005, 4055, 4053
Roadstar 4217
Roch 4031
Rover 4024, 4217
Saba 4010, 4215, 4219, 4216
Sabre 4006
Sagem 4023, 4052
Sakura 4050
Samsung 4064, 4071, 4069, 4123, 4120, 4003, 4000, 4001, 4032, 4196, 4200
SAT 4007, 4218
Sat Cruiser 4223
Sat Partner 4001, 4004, 4010, 4013, 4049, 4218
Sat Team 4217
Satcom 4012, 4219
Satec 4217
Satelco 4024
Safford 4012
Satmaster 4012
Satplus 4212
Schneider 4008, 4212, 4216
Schwaiger 4051, 4212, 4219
SCS 4215
Seemann 4011, 4009, 4014
SEG 4024, 4001, 4008, 4013
Seleco 4048
Servi Sat 4031, 4217
Siemens 4015
Silva 4049
Skantin 4217
Skardin 4009
Skinsat 4218
SKR 4217
Skymaster 4017, 4022, 4005, 4212, 4217
Skymax 4055, 4053
SkySat 4212, 4218, 4219, 4217
Skyvision 4048
SM Electronic 4212, 4217
Smart 4215, 4217
Sony 4067, 4070, 4213
SR 4011, 4054
Star Choice 4019
Starland 4217
Starring 4013
Start Trak 4001
Strong 4024, 4001, 4004, 4008, 4049, 4222
STS 4115
STVI 4031
Sumida 4011
Sunny Sound 4024
Sunsat 4217
Sunstar 4024, 4011, 4054
Supermax 4223
Tandberg 4052
Tandy 4004
Tantec 4006
TCM 4008
Techniland 4012
TechniSat 4021, 4026, 4027, 4014, 4053, 4038, 4039, 4212, 4213, 4218
Technology 4222
Technosat 4223
Technowelt 4219
Teco 4011, 4054
Telanor 4007
Telasat 4215, 4219
Telecom 4217
Telefunken 4017, 4001, 4216
Teleka 4004, 4011, 4014, 4218, 4219
Telemaster 4010

Telesat 4219
Telestar 4212, 4213, 4218
Teledes 4006, 4218
Telewire 4048
Tempo 4223
Tevion 4008, 4217
Thomson 4020, 4006, 4052, 4058, 4208, 4215, 4213, 4219, 4216, 4217
Thorens 4051
Thorn 4006
Tivax 4104
Tivo 4196
Tokai 4053
Tonna 4006, 4012, 4048, 4218, 4217
Toshiba 4194, 4202, 4203
Triad 4049
Triasat 4218
Triax 4015, 4215, 4218, 4217
Turnsat 4217
Tvonics 4214
Twiner 4031, 4217
UEC 4222
Uher 4212
UltimateTV 4070
Uniden 4079, 4127
Unisat 4011, 4050, 4053
Unitor 4013
Universum 4015, 4215, 4219
US Digital 4016
Variosat 4015
Vega 4024
Ventana 4055, 4053
Viewsat 4098
Visiosat 4013, 4048, 4216, 4217
Voom 4019
Vortec 4001
Welltech 4212
WeTeKom 4212, 4218
Wevasat 4006
Wewa 4006
Winersat 4013
Wisi 4006, 4014, 4015, 4218, 4219
Woorisat 4010
Worldsat 4216
Xrypton 4024
XSat 4217
Zehnder 4024, 4010, 4008, 4209, 4215
Zenith 4102, 4107, 4195
Zodiac 4004

CD

Yamaha 5082, 5095

CD Recorder

Yamaha 5083

MD

Yamaha 5080, 5081, 5086

Tape

Yamaha 5084, 5087

Tuner

Yamaha 5066, 5071, 5085, 5088, 5090, 5092, 5094

XM

Yamaha 5091, 5093

SIRIUS

Yamaha 5064, 5067

DOCK

Yamaha 5068, 5089

NET

Yamaha 5076, 5079

LD

Yamaha 2080

Amplifier

Yamaha 5019, 5020

YAMAHA CORPORATION

© 2010 Yamaha Corporation All rights reserved.

Ⓞ YC434A0/RC