



Digital Workstation

PSR-S975

PSR-S775

PLUS Contents List

Danh sách nội dung PLUS

## Contents

**Voice List**

Danh sách tiếng..... 2

**Style List**

Danh sách giai điệu..... 3

**Multi Pad Bank List**

Danh sách Multi Pad Bank.....3

# Voice List / Danh sách tiếng

## PSR-S975/S775

Category	Voice Name	Program Change			Voice Type
		MSB	LSB	PC# (1-128)	
Plus	SaoTieu	51	3	12	Regular
	SaoTruc	51	3	13	Regular
	KenLoa	51	3	10	Regular
	DanDay	51	3	6	Regular
	HaUyDi	51	3	9	Regular
	DanSen	51	3	7	Regular
	DanSenTremolo	51	3	17	Regular
	DanSen&Tremolo	51	3	8	Regular
	DanCo	51	3	2	Regular
	DanCoEns	51	3	11	Regular
	DanTranh	51	3	3	Regular
	DanTranhTremolo	51	3	16	Regular
	DanTranh&Tremolo	51	3	4	Regular
	DanKim	51	3	5	Regular
	DanBau	51	3	1	Regular
	DanTrung	51	3	14	Regular
	DanDa	51	3	15	Regular
	TrongCai	126	1	40	SFX
	BasicDanceHook	49	6	1	Regular
	ThreeSawMono	49	6	2	Regular
	PhatLines	49	6	3	Regular
	RawSquareStack	49	6	4	Regular
	DanceFatPoly	49	6	5	Regular
	PunchySaw	49	6	6	Regular
	MagicChords	49	6	7	Regular
	TrancyPolyHook	49	6	8	Regular
	SquareFifth	49	6	9	Regular
	SimpleTech	49	6	10	Regular
	FatSawHook	49	6	11	Regular
	MonsterHook	49	6	12	Regular
	BasicPolySynth	49	6	13	Regular
	SweepingSwell	49	6	14	Regular
	PitchWarpSweep	49	6	15	Regular
	FallingSweep	49	6	16	Regular
	FatTrancePad	49	6	17	Regular
	UniSixPad	49	6	18	Regular
	FatSawPad	49	6	19	Regular
	MonsterPad	49	6	20	Regular
	DX100Bass	49	6	21	Regular
	DanceBassVelo	49	6	22	Regular
	DanceBassDark	49	6	23	Regular
	DeepRezzBass	49	6	24	Regular
	RawSquareBass	49	6	25	Regular
	CoolSquareBass	49	6	26	Regular
	SubVeloClick	49	6	27	Regular
	SubSawBass	49	6	28	Regular
	DigiMonoBass	49	6	29	Regular
	ReverseBass	49	6	30	Regular
	BritePunchSQ	49	6	31	Regular
	JPSHORTSQ	49	6	32	Regular
	UltraShortSQ	49	6	33	Regular
	DynoDecaySQ	49	6	34	Regular
	FixStartSQ	49	6	35	Regular
	GrowlSaw	49	6	36	Regular
	GrowlSquare	49	6	37	Regular
Wobbling	49	6	38	Regular	
WhiteNoiseFall	49	6	39	Regular	
DancePowerKit	126	1	19	Live!SFX	
PowerStabs	49	6	40	Regular	
PhatDanceStabs	49	6	41	Regular	
SmoothDancePad	49	6	42	Regular	
BriteDanceComp	49	6	43	Regular	
DancePowerComp	49	6	44	Regular	
SlowResoSweep	49	6	45	Regular	
HiPassSweep	49	6	46	Regular	
DeepBEFSweep	49	6	47	Regular	
ModernFifth	49	6	48	Regular	
SquareVibrato	49	6	49	Regular	
PhatStackSQ	49	6	50	Regular	
SimpleSawSQ	49	6	51	Regular	
RawSquarePerc	49	6	52	Regular	
ReverseBassJP	49	6	53	Regular	
GrowlSquareBass	49	6	54	Regular	
BriteRezzBaz	49	6	55	Regular	

Category	Voice Name	Program Change			Voice Type
		MSB	LSB	PC# (1-128)	
Plus	MassiveBAXX	49	6	56	Regular
	DubStepBass1	49	6	57	Regular
	DubStepBass2	49	6	58	Regular
	DubStepAttack1	49	6	59	Regular
	DubStepAttack2	49	6	60	Regular
	VeloWaveBazz	49	6	61	Regular
	MagicYai	49	6	62	Regular
	DestructBaz	49	6	63	Regular
	DubStep8VeloD	49	6	64	Regular
	DubStep8VeloB	49	6	65	Regular
	DubStepMenu	49	6	66	Regular
	MysticAtmo	49	6	67	Regular
	DestructSoundFX	49	6	68	Regular
	DubStepKit	126	1	20	Live!SFX

## Style List / Danh sách giai điệu

### PSR-S975/S775

Category	Style Name
Plus	8BeatPopBallad
	6-8SlowBallad
	16BeatPop
	8BeatPop
	8BeatBallad
	GuitarBoston
	16BeatBallad
	SlowWaltz
	8BeatLightPop
	16BeatLightPop
	ModernPop
	TradPop
	AcousticDance
	OrchestralTrance
	TribalHouse
	LightDance
	GermanDJ

## Multi Pad Bank List / Danh sách Multi Pad Bank

### PSR-S975/S775

Category	Bank Name
Plus	AcousticDance A
	AcousticDance B
	AcousticDance C
	AcousticDance D
	OrchestralTrance A
	OrchestralTrance B
	OrchestralTrance C
	OrchestralTrance D
	TribalHouse A
	TribalHouse B
	TribalHouse C
	TribalHouse D
	LightDance A
	LightDance B
	LightDance C
	LightDance D
	GermanDJ A
	GermanDJ B
	GermanDJ C
	GermanDJ D